

Television: Opening Banner that says to Press Menu every time you turn your TV ON and to Turn Off the Sleep Timer

To remove the opening banner and turn off the Sleep Timer:

On the TV Remote:

Depress the "Menu" button on the Remote

Go to 'Settings'

Go to 'System'

Go to 'Media Client Settings'

Go to 'Auto Power'

Choose 'Off'

Depress 'OK' button on the Remote

Depress 'Exit' button on the Remote