

**Television: Opening Banner that says to Press Menu  
every time you turn your TV ON**  
**And**  
**To Turn Off the Sleep Timer**

To remove the opening banner and turn off the Sleep Timer:

On the TV Remote:  
Depress the "Menu" button on the Remote  
Go to 'Settings'  
Go to 'System'  
Go to 'Media Client Settings'  
Go to 'Auto Power'  
Choose 'Off '  
Depress 'OK' button on the Remote  
Depress 'Exit' button on the Remote